

- Lay out the poles, separating E, F and the octopus pole.
- Before putting the framework together put the gingham fabric tubes on the F poles, then put the framework together as shown in the diagram.
- It is essential to ensure all connectors are pushed firmly onto each pole. The 4-way connector has one leg that is longer – the long side must point upwards.
- The wooden top of the octopus pole must be at the top of the tent. If all the poles are in correctly and it is not at the top, twist the poles gently and you will find that it moves into place.
- Use the correct shape connectors for the base and roof.

- Put the roof fabric over the top of the frame work. It is designed to be a tight fit. Make sure the top of the roof is correctly in pl ace and then work down the poles. The roof is secured to the tent by velcroing it to pole E from the inside. The fabric will need two adults to put it in place.
- To attach the voile curtains sit inside the tent and velcro around the poles under the roof – the end pieces of velcro are long enough to attach around the 4-way connector. You will find tie-backs attached to the gingham fabric tubes on the F-poles.
- The floor quilt fits exactly inside the floor of the pavilion. It velcro's around the base E poles.

# Safety and care information

## Safety information

- The fabric of these play houses have been tested for flammability and adhere to the relevant European safety regulations.
  However as an additional safety precaution, no naked flames should be used in or near the play houses – keep away from fire.
- The play house is a toy. The frame is designed only to keep the cover in position and should not be subjected to additional stresses or strains.
- The fabric is 100% cotton and fully complies with European Standard BS EN 71 Parts 1, 2 & 3.

#### WARNING!

PLASTIC WRAPPING ENCLOSED. TO AVOID DANGER OF SUFFOCATION KEEP BAGS AWAY FROM BABIES AND CHILDREN

#### WARNING!

NOT SUITABLE FOR CHILDREN UNDER THE AGE OF 36 MONTHS DUE TO SMALL PARTS, CHOKING HAZARD

# Age 36+ months. Adult supervision only

- We recommend that an adult assembles our play houses and tents.
- In the interest of safety, remove all plastic bags; these can be dangerous to small children.

### Customer satisfaction

Win Green aims to supply products of the highest quality. If for any reason you are not entirely satisfied with this product please contact us on: + 44 (0)20 8295 5413. or email us at: cs@wingreen.co.uk



